



Serial PCI Express Card 4 Ports RC-305E

User Manual

Features and Benefits

Features	<ul style="list-style-type: none">● Compliant with PCI Express Base Specification 1.1● Supports 4 x UART serial port● Built-in 16C450/550 compatible UART● On chip 256 byte FIFOs in transmit and receive path of each serial port● Data transfer rate up to 230400bps
Bus	<ul style="list-style-type: none">● PCI-Express x1
Connectors	<ul style="list-style-type: none">● 4 x DB9 male serial connectors

System Requirements

- Windows® XP/Vista/7 (32/64 bit)
- PCI Express-enabled system with an available PCI Express slot

Package Contents

- 1 x PCIe Serial Card 4 Ports
- 1 x Bracket with two DB9 male serial ports
- 1 x Driver CD
- 1 x User Manual

Hardware Installation

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCIe slot.
4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

Driver Installation

1. Insert the included setup CD in your CD-ROM drive.
2. On your desktop, click "Start" then "Run".
3. When the prompt displays
 - For Windows XP 32-bit – Enter "D:\RC-305E\XP\Win32\stnsetup.exe" (where "D" is the designation of your CD drive)
 - For Windows XP 64-bit – Enter "D:\RC-305E\XP\Win64\stnsetup.exe" (where "D" is the designation of your CD drive)
 - For Windows Vista 32-bit – Enter "D:\RC-305E\Vista\Win32\stnsetup.exe" (where "D" is the designation of your CD drive)
 - For Windows Vista 64-bit – Enter "D:\RC-305E\Vista\Win64\stnsetup.exe" (where "D" is the designation of your CD drive)
 - For Windows 7 32-bit – Enter "D:\RC-305E\7\Win32\stnsetup.exe" (where "D" is the designation of your CD drive)
 - For Windows 7 64-bit – Enter "D:\RC-305E\7\Win64\stnsetup.exe" (where "D" is the designation of your CD drive)
4. Follow any on-screen instructions to complete the driver installation.
5. Restart your computer. Once you've re-booted, the adapter is ready for use.

Thank you for purchasing a quality Rosewill Product.

Please register your product at : www.rosewill.com for complete warranty information and future support for your product.