



USB3.0 Express Card 2 Ports RC-615

User Manual



Features

- Fully compliant with ExpressCard Specification 1.0
- ExpressCard/34 form factor module
- Compliant with Universal Serial Bus 3.0 specification Revision 1.0
- Supports simultaneous operation of multiple USB 3.0, USB 2.0 and USB 1.1 devices
- Supports the following speed data rates as follows:
Low-speed (1.5Mbps) / Full-speed (12Mbps) / High-speed (480Mbps) / Super-speed (5Gbps)
- Supports 2 downstream ports for all speeds
- Built-in DC Jack connector for receiving extra power to meet USB 3.0 +5V/900mA power output standard
- Hot-swapping feature allows you to connect/disconnect devices without powering down the system
- Support Windows® XP/Vista/7 (32/64 bit)

System Requirements

- Windows® XP/Vista/7 (32/64 bit)
- ExpressCard-enabled system with an available ExpressCard slot

Package Contents

- 1 x USB 3.0 2-Port ExpressCard
- 1 x USB Power Cable
- 1 x Driver CD
- 1 x User Manual

Note: Contents may vary depending on country/market.

Hardware Description



CAUTION:

Use only switching power adapter with following specifications:

- Switching power adapter (Optional) DC 5.4V, 2A
Polarity: Outside negative voltage(-) & Inside positive voltage(+)
1.3mm power DC jack for optional external power adapter



Hardware Installation

General instructions for installing the card are provided below. Since the design of system may vary, refer to your system's reference manual for further information, if needed.

Insert the Card into the ExpressCard slot of your system. Make sure it is inserted all the way in for a solid connection.

Driver Installation

For Windows® XP/Vista/7 (32/64 bit)

1. Please insert the CD driver bound with USB 3.0 2-Port ExpressCard into your CD-ROM Drive.
2. At the Windows desktop, click **Start, Run**.
3. Type **D:\RC-615\Setup.exe**, click **OK**. (Change D: to match your CD-ROM drive letter)
4. Follow the on-screen instructions to complete the installation.

To Verify Driver Installation

Click on the “**Device Manager**” tab in System Properties, which you access from the Windows Control Panel. You should see a “**NEC Electronics USB 3.0 Host Controller**” and a “**NEC Electronics USB 3.0 Root Hub**” under the “**Universal Serial Bus controllers**” item.

Thank you for purchasing a quality Rosewill Product.

Please register your product at : www.rosewill.com for complete warranty information and future support for your roduct.