



**USB 2.0 7 PORT HUB RHUB300**

User Manual



## Features

- USB 1.1 and 2.0 Compliant
- Fully Backward Compatible with USB 1.1
- Up to 480 Mbps (Megabits-Per-Second) Data Transfer Rate
- 40 Times Faster Than The USB 1.1
- Seven Independent, Fully Functional, Downstream Ports
- Hot Swappable Plug-n-Play
- 7 USB Type A Ports
- Power & USB enabled indicator LED
- No device drivers required for Hub installation
- PC Power Management
- Power Adapter (Not Included) : DC 5V/2A

## System Requirements

### PC

- Windows® 98SE, 2000, ME, XP
- USB 2.0 Compliant System

### Mac

- Mac OS 8.6 to 9.x®, Mac OS X or greater
- USB 2.0 Compliant System

## Front Panel LED Indications

LED	Status	Description
POWER	ON	Lights up when the USB 2.0 Hub is receiving power from the power source at the correct current level
USB Activity	ON	Lights up when connecting the USB 2.0 Hub to the computer's USB port

## Hardware Installation

1. Plug the Hi-Speed USB 2.0 Cable (Type B end) into the upstream port on the Hi-Speed USB 2.0 Hub.
2. Plug the Hi-Speed USB 2.0 Cable (Type A end) into your computer's Hi-Speed USB 2.0 Port.  
**Important Note** : The Hub must be connected to a USB 2.0-compliant host in order to function in high-speed mode (480Mbps data rate). If connected to a USB 1.1-compliant host, the Hub will operate only in low or full-speed mode(15/12Mbps)
3. Upon powering up your computer, the USB 2.0 hub will be recognized by the computer's operating system.
4. Once complete, you are ready to plug all peripheral devices into your new USB 2.0 Hub.

## Specification

Ports	7 Type A USB ports
Power Mode	Self or Bus Powered,
Output voltage(per port)	+5V DC
Output voltage(per port)	500mA (max.)
Operating Temperature	5-40 oC
Storage Temperature	-20-60 oC
Humidity	0-80% RH

Thank you for purchasing a quality Rosewill Product.

Please register your product at : [www.rosewill.com](http://www.rosewill.com) for complete warranty information and future support for your product.